



CAUTION:

 Output will be active on application of air if pre-set has been reached.

NOTES:

Clean dry non lubricated air to be used.
 Counters should never be adjusted while in operation.
 Pressures should not exceed counter specification.

These circuits have been designed as a concept/theory only. It is your responsibility to ensure that these details comply will all safety standards and regulations. We cannot accept responsibility for it's application. Pneumatic cylinders have been used to illustrate output functionality only. Schematic diagrams shown here may vary from actual parts supplied, although functionality will remain the same.

H.Kuhnke Limited
 Unit 21, Abbey Enterprise Centre
 Premier Way, Romsey
 Hampshire SO51 9AQ
 Tel +44 (0)1794 514445
 Fax +44 (0)1794 513514

Date : 6th July 2010
 Drawing Number 0010047

Title: Batch Counter Circuits

www.thetimerandcountercompany.com

REVISION

2					
---	--	--	--	--	--

Author: Rob Dunn

