



CAUTION:



If start button held on after counter reaches it's pre-set the output will be activated
Upon applying air system may start automatically.

NOTES:

- Clean dry non lubricated air to be used.
- Timers should never be adjusted while in operation.
- Pressures should not exceed timer specification.

These circuits have been designed as a concept/theory only. It is your responsibility to ensure that these details comply will all safety standards and regulations. We cannot accept responsibility for it's application. Schematic diagrams shown here may vary from actual parts supplied, although functionality will remain the same.

H.Kuhnke Limited
Unit 21, Abbey Enterprise Centre
Premier Way, Romsey
Hampshire SO51 9AQ
Tel +44 (0)1794 514445
Fax +44 (0)1794 513514

Date : 6th July 2010
Drawing Number 0030037

**Title: Pneumatic Digital Timer Circuit
with Pre-determined Counts Auto Stop**

www.thetimerandcountercompany.com

REVISION

3					
---	--	--	--	--	--

Author: Rob Dunn

